

# H-Type<sup>®</sup> High-Temp Precleaner with V-Tips

---

## Installation, Operation and Maintenance Manual

---



# H-Type<sup>®</sup> High Temp Precleaner with V-Tips

---

Serial Number: _____
Purchase Date: _____
Purchased From: _____
Installation Date: _____

Serial number information can be found on the Serial Number Label included in the Information Packet found in the cleaner carton.

This information will be helpful for any future inquiries or questions about belt cleaner replacement parts, specifications or troubleshooting.

# Table of Contents

---

<b>Section 1 – Important Information .....</b>	<b>4</b>
1.1 General Introduction .....	4
1.2 User Benefits .....	4
1.3 Service Option .....	4
<b>Section 2 – Safety Considerations and Precautions .....</b>	<b>5</b>
2.1 Stationary Conveyors .....	5
2.2 Operating Conveyors .....	5
<b>Section 3 – Pre-Installation Checks and Options.....</b>	<b>6</b>
3.1 Checklist .....	6
3.2 Cleaner Location Adjustments .....	7
<b>Section 4 – Installation Instructions.....</b>	<b>8</b>
4.1 Installation Instructions.....	8
4.2 Shimming Instructions .....	15
<b>Section 5 – Cleaner Pole Location Charts .....</b>	<b>16</b>
5.1 Pole Location Charts .....	16
<b>Section 6 – Pre-Operation Checklist and Testing.....</b>	<b>18</b>
6.1 Pre-Op Checklist .....	18
6.2 Test Run the Conveyor.....	18
<b>Section 7 – Maintenance .....</b>	<b>19</b>
7.1 New Installation Inspection .....	19
7.2 Routine Visual Inspection .....	19
7.3 Routine Physical Inspection.....	19
7.4 Blade Replacement Instructions.....	20
7.5 Maintenance Log .....	22
7.6 Cleaner Maintenance Checklist.....	23
<b>Section 8 – Troubleshooting .....</b>	<b>24</b>
<b>Section 9 – Specs and CAD Drawings.....</b>	<b>26</b>
9.1 Specifications and Guidelines .....	26
9.2 CAD Drawings.....	26
<b>Section 10 – Replacement Parts List.....</b>	<b>29</b>
<b>Section 11 – Other Flexco® Conveyor Products.....</b>	<b>31</b>

# Section 1 – Important Information

---

## 1.1 General Introduction

We at Flexco are very pleased that you have selected an H-Type® High Temp Precleaner with V-Tips for your conveyor system.

This manual will help you to understand the operation of this product and assist you in making it work up to its maximum efficiency over its lifetime of service.

It is essential for safe and efficient operation that the information and guidelines presented be properly understood and implemented. This manual will provide safety precautions, installation instructions, maintenance procedures and troubleshooting tips.

If, however, you have any questions or problems that are not covered, please visit our web site or contact our Customer Service Department:

**Customer Service: 91-44-6551-7771**

**Visit [www.flexco.com](http://www.flexco.com) for other Flexco locations and products.**

Please read this manual thoroughly and pass it on to any others who will be directly responsible for installation, operation and maintenance of this cleaner. While we have tried to make the installation and service tasks as easy and simple as possible, **it does however require correct installation and regular inspections and adjustments to maintain top working condition.**

## 1.2 User Benefits

Correct installation and regular maintenance will provide the following benefits for your operation:

- Reduced conveyor downtime
- Reduced man-hour labor
- Lower maintenance budget costs
- Increased service life for the belt cleaner and other conveyor components

## 1.3 Service Option

The H-Type High Temp Precleaner with V-Tips is designed to be easily installed and serviced by your on-site personnel. However, if you would prefer complete turn-key factory service, please contact your local Flexco Field Representative.

## Section 2 – Safety Considerations and Precautions

---

Before installing and operating the H-Type® High Temp Precleaner with V-Tips, it is important to review and understand the following safety information.

There are set-up, maintenance and operational activities involving both **stationary** and **operating** conveyors. Each case has a safety protocol.

---

### 2.1 Stationary Conveyors

The following activities are performed on stationary conveyors:

- Installation
- Blade replacement
- Repairs
- Tension adjustments
- Cleaning

#### **DANGER**

It is imperative that OSHA/MSHA Lockout/Tagout (LOTO) regulations, 9 CFR 1910.147, be followed before undertaking the preceding activities. Failure to use LOTO exposes workers to uncontrolled behavior of the belt cleaner caused by movement of the conveyor belt. Severe injury or death can result.

**Before working:**

- Lockout/Tagout the conveyor power source
- Disengage any takeups
- Clear the conveyor belt or clamp securely in place

#### **WARNING**

**Use Personal Protective Equipment (PPE):**

- Safety eyewear
- Hardhats
- Safety footwear

Close quarters, springs and heavy components create a worksite that compromises a worker's eyes, feet and skull.

PPE must be worn to control the foreseeable hazards associated with conveyor belt cleaners. Serious injuries can be avoided.

---

### 2.2 Operating Conveyors

There are two routine tasks that must be performed while the conveyor is running:

- Inspection of the cleaning performance
- Dynamic troubleshooting

#### **DANGER**

Every belt cleaner is an in-running nip hazard. Never touch or prod an operating cleaner. Cleaner hazards cause instantaneous amputation and entrapment.

#### **WARNING**

Belt cleaners can become projectile hazards. Stay as far from the cleaner as practical and use safety eyewear and headgear. Missiles can inflict serious injury.

#### **WARNING**

Never adjust anything on an operating cleaner. Unforseeable belt projections and tears can catch on cleaners and cause violent movements of the cleaner structure. Flailing hardware can cause serious injury or death.

## Section 3 – Pre-installation Checks and Options

---

### 3.1 Checklist

- Check that the cleaner size is correct for the beltline width
- Check the belt cleaner carton and make sure all the parts are included
- Review the “Tools Needed” list on the top of the installation instructions
- Check the conveyor site:
  - Will the cleaner be installed on a chute
  - Is the install on an open head pulley requiring mounting structure
  - Are there obstructions that may require cleaner location adjustments

## Section 3 - Pre-Installation Checks and Options (cont.)

### 3.2 Cleaner Location Adjustments

In certain applications it is necessary to modify the location of the precleaner pole due to permanent obstacles that obstruct the desired location. Relocating the pole location can be done easily and does not hinder the performance of the cleaner as long as the “C” dimension is maintained.

**NOTE:** In the following example we will be lowering the pole location in the “Y” direction, but the same method could also be applied in the “X” direction.


Conveyor situation:

Pulley Diameter: 600mm

X = 197mm

Y = 305mm

C = 362mm



- Determine the given location dimensions and define the change needed.** After laying out the given X & Y dimensions, determine the distance of the modification required for adequate clearance of the pole and tensioning system. (In the example we decide to lower the pole 50mm to clear the support structure).
- Write down known dimensions.** We can now determine two of the three required dimensions which will allow us to find the third. We know we cannot alter the “C” dimension, so this will remain the same. Also we are required to lower the unit in the “Y” dimension 50mm, so we add 50mm to the given “Y” dimension.

$$X = ?$$

$$Y = 305 + 50 = 355\text{mm}$$

$$C = 362\text{mm}$$

- Determine final dimension.** On a flat vertical surface, using a level, draw one horizontal line and one vertical line creating a right triangle (Fig 3a). Measure down from the intersection the determined “Y” dimension and mark (Fig 3b). With the tape measure starting at the modified “Y” mark, swing the tape across the “X” line and mark at the “C” dimension where it crosses the “X” line (Fig 3c). Measure from the intersection to the “C” intersection and this will be your new “X” dimension (Fig. 3d).

$$X = 67\text{mm}$$

$$Y = 355\text{mm}$$

$$C = 362\text{mm}$$




Fig. 3a




Fig. 3b




Fig. 3c





Fig. 3d

# Section 4 – Installation Instructions

## 4.1 H-Type® High Temp Precleaner with V-Tips



**Physically lock out and tag the conveyor at the power source before you begin cleaner installation.**


### Before You Begin:

- Installation specs and instructions are based on the assumption that the conveyor is in its working position (angle). If the conveyor angle will be different, the cleaner should be installed per the final position. Call 91-44-4856-6762 if you need help with determining the proper coordinates.
- Choose instructions for chute mounting or open head mounting. For chute mounting it may be necessary to cut an access hole to allow for installation and inspections. (See dimensions in Step 7 under Chute Mounting.)
- Follow all safety precautions when using a cutting torch.
- If welding, protect all fastener threads from weld spatter.

### Tools Needed

- Tape Measure
- 19mm Wrench
- Ratchet With 19mm Socket
- Adjustable Wrench
- Cutting Torch and/or Welder
- (2) 150mm C-Clamps (For Temporary Positioning of Mounting Brackets)
- 600mm Level or Eliminator Location Tool
- Marking Pen

V-Tip Size	Pulley Diameter + Belt and Lagging
SS	200 - 375mm
S	400 - 675mm
M	700 - 875mm





# Section 4 – Installation Instructions

## 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)


### Chute Mounting

- 1. Find X and Y measurements.** Find the X and Y measurement specifications for the pulley diameter. See charts on pages 14 and 15. The pulley diameter measurement should include lagging and belt.


Pulley Diameter \_\_\_\_\_; X = \_\_\_\_\_; Y = \_\_\_\_\_

Using the correct X and Y coordinates will position the cleaner at 15° below the horizontal plane on the head pulley.


- 2a. Measure head pulley shaft.** Determine the diameter of the pulley shaft and divide by 2.




- 2b. Put a level on top of the pulley shaft and draw a horizontal line A.** Measure down from Line A half the diameter of the pulley shaft and draw Line B parallel from the pulley shaft (Fig. 1).



- 3a. Mark X dimension.** Subtract the above dimension (Step 2a) from the selected X dimension to establish the modified X dimension. With this new X dimension measure horizontally from the front of the pulley shaft forward on Line B and mark on the chute (Fig. 2).



- 3b. Determine Y dimension.** From the horizontal X mark, drop a line vertically down to the selected Y dimension and draw an intersecting mark (Fig. 2a). This is the correct position of the center of the pole.




- 4. Locate mounting bracket position (horizontal position).** To locate the position of the cleaner mounting bracket, add 56mm to the intersecting mark (Fig. 2b). This mark indicates the top center of the mounting bracket.


## Section 4 – Installation Instructions

### 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)


#### Chute Mounting (cont.)




5. **Cut chute opening.** Using the adjusted intersecting mark (“+”) established in Step 4, lay out and cut the required opening 125 x 150mm on the chute (Fig. 3). If access hole is required, see Step 7.




6. **Install the mounting brackets.** Center the mounting bracket on the bottom of the opening. Bolt or weld in position (Fig 4). Repeat process on opposite side.



7. **Cutting the access hole.** Cut access hole, centering the bottom edge on the adjusted intersecting mark (“+”) established in Step 4. Width of hole should be 125mm; height should be 238mm for extra small tips, 300mm for small tips or 338mm for medium tips. Access hole may be oriented within the range shown (Fig. 5), provided bottom edge is still centered as described above.



8. **Install the pole.** Remove the two bearing mount bolts from one of the bearing mounts (Fig. 6). (If chute mount, remove from the side with access hole.) Slide the pole across the pulley and into the bearing mount on other side and allow tips to hang down. Install the removed bearing mount on the pole and reattach to the mounting bracket. Do not tighten; leave finger tight.



9. **Position the pole.** Rotate pole upward to bring tips into contact with head pulley (Fig. 7). Center the tips across the belt. While applying light pressure on the center tip, shift loosened bearing mount until tips are contacting belt evenly across full width. Lock cleaner into this position by tightening bearing mount bolts.

For step-by-step instructions on installing the spring tensioner, refer to page 12.

## Section 4 – Installation Instructions

### 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)

#### Open Head Mounting




Fig. 1




Fig. 2




Fig. 3

- 1. Find X and Y measurements.** Find the X and Y measurement specifications for the pulley diameter. See charts on pages 14 and 15. The pulley diameter measurement should include lagging and belt.

Pulley Diameter \_\_\_\_\_ X \_\_\_\_\_ Y \_\_\_\_\_

Using the correct X and Y coordinates will position the cleaner at 15° below the horizontal plane on the head pulley.

- 2a. Locate Y location.** Determine the diameter of the pulley shaft and divide by 2.
- 2b. Put a level on top of the pulley shaft and mark A at the structure.** Measure down from Mark A half the diameter of the pulley shaft and mark B, locating the shaft centerline (Fig. 1).
- 2c. Measure down the given Y dimension plus 56mm and mark (Fig. 2).** This mark indicates the top location of support material to be added for installing the cleaner mounting brackets.

a) shaft to structure	_____	
b) pulley shaft diameter _____ ÷ 2	_____	+
c) pulley shaft center line to structure	= _____	
d) add X measurement from chart	_____	+
center of pole from structure	= _____	
e) add 175mm (7") (half length of mounting bracket)	175mm	+
<b>length of support material needed</b>	= _____	

- 3. Locate X location.**
  - a.) Measure from the back of the pulley shaft to the support structure (Fig. 3).
  - b.) Pulley shaft diameter divided by 2.
  - c.) Add dimensions from a) and b). This dimension is the pulley shaft centerline to the support structure.
  - d.) Add the given X dimension to c). The sum indicates the distance from the center of the pole to the support structure.
  - e.) Add 175mm (half the length of the mounting bracket). The sum is the total length of support material needed to correctly locate the mounting brackets.
- 4. Secure mounting support pieces to the support structure.** Weld support pieces to the support structure. 75 x 75mm angle works well for these support pieces.
- 5. Prepare the support pieces for the cleaner mounting brackets.** Clamp the mounting bracket on the support piece. Mark and drill holes for mounting or weld.

## Section 4 – Installation Instructions

### 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)

#### Open Head Mounting (cont.)




Fig. 6

6. **Install the pole.** Remove the two bearing mount bolts from one of the bearing mounts (Fig. 6). (If chute mount, remove from the side with access hole.) Slide the pole across the pulley and into the bearing mount on other side and allow tips to hang down. Install the removed bearing mount on the pole and reattach to the mounting bracket. **NOTE:** Do not tighten; leave finger tight.




Fig. 7

7. **Position the pole.** Rotate pole upward to bring tips into contact with head pulley (Fig. 7). Center the tips across the belt. While applying light pressure on the center tip, shift loosened bearing mount until tips are contacting belt evenly across full width. Lock cleaner into this position by tightening bearing mount bolts.

#### Spring Tension Mounting Kit




Fig. 1





Fig. 2

- 8a. **Install the Tensioning System.** With the pole rotated up so that all the tips contact the head pulley, slide a collar on each end of the pole. Position the collars tight against the bearing mounts and tighten the lock bolt and jam nut on each collar (Fig. 1).
- 8b. **Assemble the tension spring and the J bolt mount to an adjusting arm (Fig. 2).** **IMPORTANT:** Allow for at least 100 to 125mm upward movement on the J bolt for future blade tip adjustments.


## Section 4 – Installation Instructions

### 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)

#### Spring Tension Mounting Kit (cont.)



- 8c. Install an adjusting arm onto pole end.** Rotate the tensioner around the pole until the optimum mounting position is located. The J bolt mount can be located in any position 360° around the pole. The only requirement is that the J bolt and spring remain perpendicular to the adjusting arm (Fig. 3). **NOTE:** adjusting arm can be located any place along the end of the pole to align with J bolt mount.
- 8d. Clamp the J bolt mount in place and weld or bolt in position.**
- 8e. With the adjusting arm positioned perpendicular to the J bolt mount, tighten the adjusting arm lock bolts and jam nuts (for optimum hold, tighten the back bolt first and then the top bolt).**
- 8f. The 900mm, 1050mm & 1200mm size cleaners require a dual tensioner.** Repeat steps b through e) on other side of cleaner.




- 9. Set the Spring Tension.** Loosen the J bolt jam nut and turn the tensioner adjusting nut until the coil is 125mm long. Measure the length of the white line on the spring (Fig. 4). Complete on both sides of cleaner, if required. **NOTE:** The given spring length measurement is a starting point only. Actual length for correct cleaner blade tensioning may vary by cleaner width. Determine exact spring measurement length for your cleaner after Step 12HT is completed.

## Section 4 – Installation Instructions

### 4.1 H-Type® High Temp Precleaner with V-Tips (cont.)

#### Spring Tension Mounting Kit (cont.)

- 10. Check for Correct Blade Tip Tension.** Place the Tip Tension Gauge (supplied with cleaner) between the blade tip and belt on the center tip (or tips) (Fig. 5). While pulling in a straight motion, read the tension required to break contact between the tip and belt. 8Kg is recommended. Also check tension on both outer tips. Make tension adjustments if needed.



- 11. Measure Spring Length and Affix Label.** After the correct spring tension has been confirmed, measure the white line on the spring. Using a ballpoint pen mark the spring length on the Spring Length label provided in the packet. Affix the label on the conveyor structure near the spring for future reference for tensioning or re-tensioning the blades.

# Section 4 – Installation Instructions

## 4.2 Shimming Instructions





### Tools Needed:

- (1) 38mm wrench or crescent wrenches
- (1) 38mm wrenches or crescent wrenches
- Shim Kit (provided)




**NOTE:** If all cleaner tips do not make even contact across the width of the belt, the tips will require shimming (Fig. A and Fig. B).

All shimming is done between the suspension arm bases and the pole plate (Fig. 2).

1. **Remove tension.** Turn adjusting bolt down until a 3mm gap is gained at the tightest point between the tip and the belt (Fig. 1).
2. **Loosen both suspension arm nuts on tip to be shimmed.** Push the tip against the head pulley to move the suspension arms away from the pole plate (Fig. 2).




3. **Determine where to place the shim** (use plastic shims provided).
  - a. To move tip in equally at both ends, place long shim above the suspension arm studs, centered on the two studs (Fig. 3a).
  - b. To move tip in at one end only, place a short shim above the suspension arm stud on the side that must be pulled in (Fig. 3b).
  - c. Shim tips until 3mm gap is obtained across the entire cleaner width (Fig. 3c).



4. **Reset tip tension.**


# Section 5 – Cleaner Pole Location Charts

## 5.1 Pole Location Charts



**Extra Small (SS) V-Tips for Head Pulley Diameters 200 to 375 mm**

Diameter (Over Belt)	X	Y	C	Gap
200	25	197	197	67
225	38	199	200	59
250	50	200	210	54
275	65	206	216	50
300	75	210	222	44
325	86	213	225	41
350	98	216	238	38
375	111	219	248	35




**Small (S) V-Tips for Head Pulley Diameters 400 to 675 mm**

Diameter (Over Belt)	X	Y	C	Gap
400	98	275	295	67
425	111	283	302	64
450	121	286	311	57
475	133	286	318	54
500	146	292	327	50
525	159	295	337	48
550	171	298	343	44
575	184	299	352	41
600	197	300	362	38
625	210	308	372	38
650	219	311	375	35
675	231	314	391	32



# Section 5 – Cleaner Pole Location Charts

## 5.1 Pole Location Charts (cont.)



**Medium (M) V-Tips for Head  
Pulley Diameters 700 to 875 mm**

Diameter (Over Belt)	X	Y	C	Gap
700	225	362	429	57
725	231	368	438	54
750	250	371	448	50
775	267	372	460	48
800	275	374	470	48
825	292	375	479	44
850	300	384	489	41
875	314	387	498	41

## Section 6 – Pre-Operation Checklist and Testing

---

### 6.1 Pre-Op Checklist

- Recheck that all fasteners are tightened properly.
- Add pole caps.
- Apply all supplied labels to the cleaner .
- Check the blade location on the belt.
- Be sure that all installation materials and tools have been removed from the belt and the conveyor area.

### 6.2 Test Run the Conveyor

- Run the conveyor for at least 15 minutes and inspect the cleaning performance.
- Check the tensioner spring for recommended length (proper tensioning).
- Make adjustments as necessary.

**NOTE:** Observing the cleaner when it is running and performing properly will help to detect problems or when adjustments are needed later.

## Section 7 – Maintenance

---

Flexco belt cleaners are designed to operate with minimum maintenance. However, to maintain superior performance some service is required. When the cleaner is installed a regular maintenance program should be set up. This program will ensure that the cleaner operates at optimal efficiency and problems can be identified and fixed before the cleaner stops working.

All safety procedures for inspection of equipment (stationary or operating) must be observed. The H-Type® Precleaner operates at the discharge end of the conveyor and is in direct contact with the moving belt. Only visual observations can be made while the belt is running. Service tasks can be done only with the conveyor stopped and by observing the correct lockout/tagout procedures.

### 7.1 New Installation Inspection

After the new cleaner has run for a few days a visual inspection should be made to ensure the cleaner is performing properly. Make adjustments as needed.

### 7.2 Routine Visual Inspection (every 2-4 weeks)

A visual inspection of the cleaner and belt can determine:

- If the spring length is the correct length for optimal tensioning.
- If the belt looks clean or if there are areas that are dirty.
- If the blade is worn out and needs to be replaced.
- If there is damage to the blade or other cleaner components.
- If fugitive material is built up on the cleaner or in the transfer area.
- If there is cover damage to the belt.
- If there is vibration or bouncing of the cleaner on the belt.
- If a snub pulley is used, a check should be made for material buildup on the pulley.

If any of the above conditions exist, a determination should be made on when the conveyor can be stopped for cleaner maintenance.


### 7.3 Routine Physical Inspection (every 6-8 weeks)

When the conveyor is not in operation and properly locked and tagged out a physical inspection of the cleaner to perform the following tasks:

- Clean material buildup off the cleaner blade and pole.
- Closely inspect the blade for wear and any damage. Replace if needed.
- Check both blade pins for proper installation and condition. Replace if needed.
- Ensure full blade to belt contact.
- Inspect the cleaner pole for damage.
- Inspect all fasteners for tightness and wear. Tighten or replace as needed.
- Replace any worn or damaged components.
- Check the tension of the cleaner blade to the belt. Adjust the tension if necessary.
- When maintenance tasks are completed, test run the conveyor to ensure the cleaner is performing properly.

## Section 7 – Maintenance

### 7.4 Blade Replacement Instructions




**Physically lock out and tag the conveyor at the power source before you begin cleaner installation.**


#### Tools Needed

- Tape measure
- (2) 38mm wrenches or crescent wrenches
- (1) 17mm wrench
- Wire brush (for cleaning pole)
- Small putty knife (for cleaning pole)

1. **Remove the tension.** Loosen the adjusting nuts on the mounting bracket/J-bolt assembly to remove tension from the arm (Fig. 1). This releases the tension of the blade on the belt.



2. **Remove the worn tips.** Remove the nuts on each tip and remove the tips from the cushion (Fig. 2). Clean all fugitive material from the pole. **NOTE:** If tips are hard to remove use a screwdriver or hammer to loosen it and then remove.



## Section 7 – Maintenance

### 7.4 Blade Replacement Instructions (cont.)

3. **Install the new tips.** Locate each tip onto each suspension arm, then install the hardware to fasten the tip to the cushion (Fig. 3).
4. **Reset the correct blade tension.** Loosen the J bolt jam nut and turn the tensioner adjusting nut until the coil is 125mm long. Measure the length of the white line on the spring (Fig. 4). Complete on both sides of cleaner, if required. **NOTE:** The given spring length measurement is a starting point only. Actual length for correct cleaner blade tensioning may vary by cleaner width.

**Test run the cleaner.** Run the conveyor for at least 15 minutes and inspect the cleaning performance. Check the spring length for proper tensioning. Make adjustments as necessary.




Fig. 3




Fig. 4

# Section 7 – Maintenance

---

## 7.5 Maintenance Log

Conveyor Name/No. \_\_\_\_\_

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

Date: \_\_\_\_\_ Work done by: \_\_\_\_\_ Service Quote #: \_\_\_\_\_

Activity: \_\_\_\_\_

---

# Section 7 – Maintenance

## 7.6 Cleaner Maintenance Checklist

Site: \_\_\_\_\_ Inspected by: \_\_\_\_\_ Date: \_\_\_\_\_

Belt Cleaner: \_\_\_\_\_ Serial Number: \_\_\_\_\_

### Beltline Information:

Beltline Number: \_\_\_\_\_ Belt Condition: \_\_\_\_\_

Belt Width:  450mm (18")  600mm (24")  750mm (30")  900mm (36")  1050mm (42")  1200mm (48")  1350mm (54")  1500mm (60")  1800mm (72")

Head Pulley Diameter (Belt & Lagging): \_\_\_\_\_ Belt Speed: \_\_\_\_\_ fpm or m/s Belt Thickness: \_\_\_\_\_

Belt Splice: \_\_\_\_\_ Condition of Splice: \_\_\_\_\_ Number of Splices: \_\_\_\_\_  Skived  Unskived

Material conveyed: \_\_\_\_\_

Days per week run: \_\_\_\_\_ Hours per day run: \_\_\_\_\_

### Blade Life:

Date blade installed: \_\_\_\_\_ Date blade inspected: \_\_\_\_\_ Estimated blade life: \_\_\_\_\_

Is blade making complete contact with belt?  Yes  No

Blade wear: Left \_\_\_\_\_ Middle \_\_\_\_\_ Right \_\_\_\_\_

Blade condition:  Good  Grooved  Smiled  Not contacting belt  Damaged

Measurement of spring: Required \_\_\_\_\_ Currently \_\_\_\_\_

Was Cleaner Adjusted:  Yes  No

Pole Condition:  Good  Bent  Worn

Lagging:  Side Lag  Ceramic  Rubber  Other  None

Condition of lagging:  Good  Bad  Other \_\_\_\_\_

Cleaner's Overall Performance: (Rate the following 1 - 5, 1= very poor - 5 = very good)

Appearance:  Comments: \_\_\_\_\_

Location:  Comments: \_\_\_\_\_

Maintenance:  Comments: \_\_\_\_\_

Performance:  Comments: \_\_\_\_\_

Other comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Section 8 – Troubleshooting

Problem	Possible Cause	Possible Solutions
Poor cleaning performance	Cleaner under-tensioned	Adjust to correct tension – see spring length chart
	Cleaner over-tensioned	Adjust to correct tension – see spring length chart
	Cleaner installed in wrong location	Verify "C" dimension, relocate to correct dimension
	Cleaner blade worn or damaged	Replace cleaner blade
Rapid Blade Wear	Tension on cleaner too high/low	Adjust to correct tension – see spring length chart
	Cleaner not located correctly	Check cleaner location for correct dimensions
	Blade attack angle incorrect	Check cleaner location for correct dimensions
	Material too abrasive for blade	Option: switch to alternate cleaner with metal blades
	Mechanical splice damaging blade	Repair, skive or replace splice
Center wear on blade (smile effect)	Blade wider than material path	Replace blade with width to match material path
	Tension on cleaner too high/low	Adjust to correct tension – see spring length chart
Unusual wear or damage to blade	Mechanical splice damaging blade	Repair, skive or replace splice
	Belt damaged or ripped	Repair or replace belt
	Cleaner not correctly located	Verify "C" dimension, relocate to correct dimension
	Damage to pulley or pulley lagging	Repair or replace pulley
Vibration or noise	Cleaner not located correctly	Verify "C" dimension, relocate to correct dimension
	Blade attack angle incorrect	Verify "C" dimension, relocate to correct dimension
	Cleaner running on empty belt	Use a spray pole when the belt is empty
	Cleaner tension too high/low	Adjust to correct tension or slight adjust to diminish
	Cleaner locking bolts not secure	Check and tighten all bolts and nuts
	Cleaner not square to head pulley	Verify "C" dimension, relocate to correct dimension
	Material buildup in chute	Clean up build-up on cleaner and in chute
Cleaner being pushed away from pulley	Cleaner tension not set correctly	Ensure correct tension/increase tension slightly
	Sticky material is overburdening cleaner	Increase tension; replace with cleaner with metal tips; replace with larger size cleaner
	Cleaner not set up correctly	Confirm location dimensions are equal on both sides




# Section 9 – Specs and CAD Drawings

## 9.1 Specifications and Guidelines

### Pole Length Specifications\*


Cleaner Size		Pole Length		Maximum Conveyor Span	
mm	in.	mm	in.	mm	in.
450	18	1650	66	1400	56
600	24	1800	72	1550	62
750	30	1950	78	1700	68
900	36	2100	84	1850	74
1050	42	2250	90	2000	80
1200	48	2400	96	2150	86

\*For special extra long pole length requirements a Pole Extender Kit.  
Pole Diameter - 60mm



### Clearance Guidelines for Installation

Suspension Arm Size	Horizontal Clearance Required		Vertical Clearance Required	
	mm	in.	mm	in.
SS	175	7	229	9
S	175	7	279	11
M	175	7	318	12 1/2




### Specifications:

- Maximum Belt Speed ..... 5m/s
- Temperature Rating ..... -35°C to 204°C
- Blade Thickness ..... 9mm
- Blade Material..... Long Life Tungsten Carbide (for vulcanized belts only)
- Available for Belt Widths ..... 450 to 1200mm.  
..... Other sizes available upon request.
- CEMA Cleaner Rating ..... Class 3

# Section 9 – Specs and CAD Drawings

## 9.2 CAD Drawing - High Temp Precleaner with V-Tips - SS




DIAMETER (OVER BELLET)	X	Y	C	GAP
8	1	7-3/4	7-3/4	2-5/8
9	1-1/2	7-7/8	8	2-3/8
10	2	8	8-1/4	2-1/8
11	2-1/2	8-1/8	8-1/2	2
12	3	8-1/4	8-3/4	1-3/4
13	3-3/8	8-3/8	9	1-5/8
14	3-7/8	8-1/2	9-3/8	1-1/2
15	4-3/8	8-5/8	9-3/4	1-3/8

C LEANER	BELT WIDTH	"A"	"B"	NO. OF BLADES
74821	18"	48"	15.75"	2
74822	24"	54"	23.62"	3
74823	30"	60"	23.62"	3
78424	36"	66"	31.45"	4
74825	42"	72"	39.37"	5
74826	48"	78"	39.37"	5

# Section 9 – Specs and CAD Drawings

## 9.2 CAD Drawing - High Temp Precleaner with V-Tips - S




DIAMETER (OVER BELT)	X	Y	C	GAP
16	3-7/8	11	11-5/8	2-5/8
17	4-3/8	11-1/8	11-7/8	2-1/2
18	4-3/4	11-1/4	12-1/4	2-1/4
19	5-1/4	11-3/8	12-1/2	2-1/8
20	5-3/4	11-1/2	12-7/8	2
21	6-1/4	11-5/8	13-1/4	1-7/8
22	6-3/4	11-3/4	13-1/2	1-3/4
23	7-1/4	11-7/8	13-7/8	1-5/8
24	7-3/4	12	14-1/4	1-1/2
25	8-1/4	12-1/8	14-5/8	1-1/2
26	8-5/8	12-1/4	15	1-3/8
27	9-1/8	12-3/8	15-3/8	1-1/4

CLEANER	BELT WIDTH	"A"	"B"	NO. OF BLADES
74828	18"	48"	15.75"	2
74829	24"	54"	23.62"	3
74830	30"	60"	23.62"	3
74831	36"	66"	31.45"	4
74832	42"	72"	39.37"	5
74833	48"	78"	39.37"	5



# Section 9 – Specs and CAD Drawings

## 9.2 CAD Drawing - High Temp Precleaner with V-Tips - M







POLE LOCATION CHART				
DIAMETER (INCLUDING BELT)	X	Y	C	GAP
*26	7-1/4	17-5/8	19	2-3/8
*27	7-3/4	17-3/4	19-3/8	2-3/8
*28	8-1/4	17-7/8	19-5/8	2-1/4
*29	8-3/4	18	20	2-1/8
*30	9-1/4	18-1/8	20-3/8	2
31	9-3/4	18-1/4	20-5/8	1-7/8
32	10-1/8	18-3/8	21	1-7/8
33	10-5/8	18-1/2	21-3/8	1-3/4
34	11-1/8	18-5/8	21-3/4	1-5/8
35	11-5/8	18-3/4	22-1/8	1-5/8
36	12-1/8	18-7/8	22-3/8	1-1/2
37	12-5/8	19	22-3/4	1-3/8
38	13-1/8	19-1/8	23-1/8	1-3/8
39	13-1/2	19-1/4	23-5/8	1-1/4
*40	14	19-3/8	24	1-1/4
*41	14-1/2	19-1/2	24-3/8	1-1/8
*42	15	19-5/8	24-3/4	1-1/8
*43	15-1/2	19-3/4	25-1/8	1-1/8
*44	16	19-7/8	25-1/2	1
*45	16-1/2	20	26	1

\* OPTIONAL EXTENDED RANGE

CLEANER	BELT WIDTH	"A"	"B"	NO. OF BLADES
76191	18"	60"	15.75"	2
76193	24"	66"	23.62"	3
76195	30"	72"	23.62"	3
76197	36"	78"	31.50"	4
76251	42"	84"	39.38"	5
76255	48"	90"	39.38"	5
76258	54"	96"	47.25"	6
76261	60"	108"	55.12"	7
76264	72"	120"	63.00"	8

## Section 10 – Replacement Parts List



### Replacement Parts

Ref	Description	Ordering Number	Item Code	Wt. Kg
1	450mm Pole	HP-18	78990	10.0
	600mm Pole	HP-24	78991	4.5
	750mm Pole	HP-30	78992	13.2
	900mm Pole	HP-36	78993	15.0
	1050mm Pole	HP-42	78994	19.5
	1200mm Pole	HP-48	78995	21.3
2	H V-Tip S/S (for vulcanized belts only)	HVT8-S/S	75419	0.5
3	H SS Suspension Arm*	HSA8SS	73047	0.2
	H S Suspension Arm*	HSA8S	73048	0.5
	H M Suspension Arm*	HSA8M	73049	0.7
4	H SS Tip Shield	HSSTS	74771	0.2
5	H Mounting Bracket Repair Kit* (includes 1 mounting bracket)	HMRK	74582	4.5
6	H Bearing Repair Kit* (includes 1 bearing)	HBRK	73068	2.7
7	H Adjusting Arm Repair Kit* (includes 1 adjusting arm)	HAR-K	78786	2.7
8	J-Bolt Kit* (includes 1 ea.)	STJK	74417	0.3
9	HT Tension Spring (includes 1 ea.)	HTTS-HT	79068	0.6
10	Spring Tensioner J-Bolt Mount (incl. 1 ea.)	STJM	74775	1.4

\*Hardware included  
Pole Diameter - 60mm  
Lead time: 1 working day

Ref	Description	Ordering Number	Item Code	Wt. Kg
-	H Mounting/J-Bolt Kit - Single (incl. 1 ea. items 5, 6, 7, 8, 9, & 10) (for sizes 450 to 750 mm)	H-MK1	78987	9.1
-	H Mounting/J-Bolt Kit - Dual (incl. 2 ea. items 5, 6, 7, 8, 9, & 10) (for sizes 900 to 1200 mm)	H-MK2	78801	11.1
-	Spring Tension Kit - Single (incl. 1 ea. items 8, 9, & 10) (for sizes 450 to 750 mm)	STKS	74505	3.1
-	Spring Tension Kit - Dual (incl. 2 ea. items 8, 9, & 10) (for sizes 900 to 1200 mm)	STKD	74504	5.1
11	H Bolt Tensioner Kit (includes 2 adjusting bolts & 2 jam nuts)	HBTK	74776	0.2



## Section 11 – Other Flexco Conveyor Products

---

Flexco provides many conveyor products that help your conveyors to run more efficiently and safely. These components solve typical conveyor problems and improve productivity. Here is a quick overview on just a few of them:

### Rockline® EZP1 Precleaner



- Patented ConShear™ blade renews its cleaning edge as it wears
- Visual Tension Check™ for optimal blade tensioning and simple retensioning
- Quick and easy one-pin blade replacement Material Path Option™ for optimal cleaning and reduced maintenance

### DRX Impact Beds



- Exclusive Velocity Reduction Technology™ to better protect the belt
- Slide-Out Service™ gives direct access to all impact bars for change-out
- Impact bar supports for longer bar life
- 4 models to custom fit to the application

### Rockline® EZS2 Secondary Cleaner



- Long-wearing tungsten carbide blades for superior cleaning efficiency
- Patented FormFlex™ cushions independently tension each blade to the belt for consistent, constant cleaning power
- Easy to install, simple to service
- Works with Flexco mechanical belt splices

### PT Max™ Belt Trainer



- Patented “pivot & tilt” design for superior training action
- Dual sensor rollers on each side to minimize belt damage
- Pivot point guaranteed not to freeze or seize up
- Available for topside and return side belts

### Flexco Specialty Belt Cleaners



- “Limited space” cleaners for tight conveyor applications
- High Temp cleaners for severe, high heat applications
- A rubber fingered cleaner for chevron and raised rib belts
- Multiple cleaner styles in stainless steel for corrosive applications

### Belt Plows



- A belt cleaner for the tail pulley
- Exclusive blade design quickly spirals debris off the belt
- Economical and easy to service
- Available in vee or diagonal models

New Door No. 51 • Anna Salai, Nagalkeni • Pammal Village • Chennai - 600 044 • Tamil Nadu • India  
Tel: +91-44-4856-6762 • E-mail: info.india@flexco.com

Visit [www.flexco.com](http://www.flexco.com) for other Flexco locations and products.

©2021 Flexible Steel Lacing Company. 11/09/21. For reorder: X4756

