

R2T Tool Anvil Inserts

Installation Instructions

1. Insert anvil into proper location.

2. Use nail/rivet assembly to drive the insert in.

***NOTE:** Do not pre-insert anvils and then finish hitting them with a hammer. Hitting directly on the insert can distort it enough to render it useless. You may use a piece of flat steel or the equivalent to serve as a buffer between hammer blows and the insert.*

R2/305

X0653