

HINGE PIN RETAINING COLLARS
INSTALLATION INSTRUCTIONS

Installation:

1. Insert and center hinge pin in splice.
2. Place first Retaining Collar over one end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
3. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely.
4. Place second Retaining Collar over opposite end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
5. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely

For Reorder: X2296

HINGE PIN RETAINING COLLARS
INSTALLATION INSTRUCTIONS

Installation:

1. Insert and center hinge pin in splice.
2. Place first Retaining Collar over one end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
3. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely.
4. Place second Retaining Collar over opposite end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
5. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely

For Reorder: X2296

HINGE PIN RETAINING COLLARS
INSTALLATION INSTRUCTIONS

Installation:

1. Insert and center hinge pin in splice.
2. Place first Retaining Collar over one end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
3. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely.
4. Place second Retaining Collar over opposite end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
5. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely

For Reorder: X2296

HINGE PIN RETAINING COLLARS
INSTALLATION INSTRUCTIONS

Installation:

1. Insert and center hinge pin in splice.
2. Place first Retaining Collar over one end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
3. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely.
4. Place second Retaining Collar over opposite end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
5. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely

For Reorder: X2296

HINGE PIN RETAINING COLLARS
INSTALLATION INSTRUCTIONS

Installation:

1. Insert and center hinge pin in splice.
2. Place first Retaining Collar over one end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
3. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely.
4. Place second Retaining Collar over opposite end of hinge pin. (Leave approximately 3/8" gap between the collar and the splice end loop)
5. Loosely set all three screws evenly around the hinge pin so all knurled points are in contact with the hinge pin. -
Then finish tightening all three screws securely

For Reorder: X2296