
FLEX-SEAL™ Skirting System

Solves Spillage and Dust Control Problems

Flex-Seal Skirting System is a dynamic containment unit that fully seals the loading zone. It stops material spillage leaks, controls dust emissions and helps prevent other resulting problems such as belt damage. Conventional skirt clamps and systems may contain spillage of materials, but maintenance is typically difficult and time-consuming. And more importantly, the damage done to the conveyor belt is costly. The Flex-Seal Skirting System creates a parallel seal with the belt to be effective for your operation.



Features and Benefits

- No belt damage. With correct installation, the skirt rubber will not drag on the belt, causing premature wear or gouge marks in the belt cover. Such damage reduces belt cleaning efficiency and the life of the belt.
- **Safe service access.** All installation and maintenance work can be done safely from the sides of the conveyor. Climbing into the chute to work on nuts and bolts is not required.
- Long service life. Flex-Seal Skirting Systems are made of corrosion-protected components for tough duty. Replacement parts are available.



FLEX-SEAL™ Skirting System

Ordering Information

Flex-Seal Skirt System*					
Description	Ordering Number	Item Code			
Flex-Seal Skirt System	CRMC2-FS-1	81995			

^{*} Includes angle plate, one Bolt-On PAL PAK, and one 1.2M Clamp Bar. Skirt board and rubber not included.

01.	. D. I.		This law	D .		0	. 10
SKIR	T KIIN	ner	Inickne	ass Ha	indes:	xmm t	ი 19mm

Replacement Parts*					
Description	Ordering Number	Item Code			
Angle Plate	CRMC2-SSAPK	81996			
Bolt-On PAL PAK*	CRMC1-BPP	81984			
Clamp Bar	CRMC1-CB	81990			

^{*}Includes two bolt-on clamp pins and two clamp plates.

Specifications				
Skirt Rubber Width and Thickness Range				
Width Required	150mm			
Thickness Range	8-19mm			





Bolt-On PAL PAK

Additional Information

Check out our other Skirting Systems, like the RMC1 or Flex-Lok.

RMC1





Flexco (Aust.) Pty. Ltd • 10 Solent Circuit • Baulkham Hills NSW 2153 • Australia Tel: 612-8818-2000 • Fax: 612-8824-6333 • E-mail: salesau@flexco.com

Visit www.flexco.com for other Flexco locations and products.

©2018 Flexible Steel Lacing Company. 11/14/18. For reorder: X1943

