



## ALLIGATOR® STAPLE GOLD CLASS™ PLUS

### Reduce Installation Time by 35% and Improve Splice Consistency

#### **Faster.**

The Gold Class™ power driver, in conjunction with the Gold Class Plus tool allows users to install Alligator® Ready Set™ staple plates with quick and effortless trigger pulls. The design of the Gold Class Plus tool allows users to switch between plate sizes in mere seconds.

#### **Easier.**


The Gold Class Plus tool combines both the initial and final set function in a single base. This process is not only fast and easy, but it is also virtually error proof. The patented drive punch has been designed to seat the front edge of the fastener plate down for proper compression, while also keeping the fastener loops protected. This ensures smooth hinge pin insertion.

#### **Safer.**

By eliminating the need to use a hammer to install the fasteners, the Alligator Staple Gold Class system reduces the risk of repetitive motion injuries. It also reduces operator fatigue associated with hammer installing numerous splices throughout the day.



*Rapid transition between staple sizes is possible with the unique Gold Class™ Plus comb design.*



### 3 Simple Steps:

## ALLIGATOR® STAPLE GOLD CLASS™ PLUS



#### Initial Set:

Fasteners and belt are inserted into the base where the pre-staked staples are driven through the belt with simple trigger pulls.



#### Simple Adjustment:

After the fasteners are initially set, simply flip the handle.



#### Final Set:

With additional trigger pulls, the staples receive their final set and the compression fit is obtained.

Ordering Information		
Description	Ordering Number	Item Code
Alligator® Staple Gold Class™ Plus Installation Tool		
610 mm (24") Alligator Gold Class Plus Installation Tool	RS-GOLD-DA	55590
Replacement Parts		
Guide Block	ST7-5	55554
Anvil Replacement Kit	ST8-ANV	55591
Cam Lever	ST8-CAM	55592
Alligator® Staple Gold Class™ Power Driver		
Power Driver	RS-GOLD-DRIVER	55541



Profiled front edge of the drive punch creates proper compression set of the front edge of the fastener plate.

Authorised Distributor:

Flexco Europe GmbH • Maybachstrasse 9 • 72348 Rosenfeld • Germany  
Tel: +49-7428-9406-0 • Fax: +49-7428-9406-260 • E-mail: europe@flexco.com

Visit [www.flexco.com](http://www.flexco.com) for other Flexco locations and products.

©2012 Flexible Steel Lacing Company. Alligator® is a registered trademark. 10-22-20. For Reorder: X5257

