



Smart Technology for Smarter Splicing

CONNECTIVITY

Improve splice reliability and enhance press productivity.

Utilizing BLE, the Novitool® Aero® Splice Press with IntelliSplice™ Technology connects to the Aero Mobile App to input, edit, and delete recipes and uploads splice cycle data. Utilizing Wi-Fi for quick over-the-air firmware updates.

OPERATIONAL EFFICIENCY

Keep up-to-date on all the latest technological improvements to the Aero® Press.

Ongoing updates and improvements to press operation—based on customer feedback and technology innovations—means your press is continually optimized for the most efficient operation and consistent endless splicing.

SPLICE RELIABILITY YOU CAN TRUST

The Aero® Dashboard gives operators instant access to detailed splice cycle data for easy evaluation and troubleshooting.

Whether managing a single press or an entire fleet, the intuitive dashboard simplifies operations. Plus, operators can connect directly with Flexco Aero Press experts for advanced splicing support and personalized assistance.



● Novitool® Aero® Splice Press with IntelliSplice™ Technology

- Simply register your press by adding your press to the Aero® Dashboard
- Download the Aero® Mobile App
- Connect to your press



QUICK START GUIDE

NOVITOOL® AERO® SPLICE PRESS WITH INTELLISPLICE™ TECHNOLOGY

Connecting your Aero® Splice Press with IntelliSplice™ Technology is easy. Just follow the simple steps below.



INITIALIZE PRESS

Initialize your new Aero Splice Press by registering the unique serial number at www.flexco.com/code.



ACCESS DASHBOARD

Immediately following the online registration, you will receive an email inviting you to log-in and add presses and users to the custom Dashboard.
<https://Novitool.Flexco.cloud>



DOWNLOAD THE AERO® MOBILE APP

Using your smart device, search your Apple or Android App Store for "Novitool® Aero® Splice Press".

Download the Aero® Mobile App and log-in using your Dashboard user name and password.



MAKE THE CONNECTION

Use the Aero® Mobile App and connect via BLE.



RECIPE MANAGEMENT

Enter, edit, and delete recipes from your smart device syncing recipes back to the press.






TRANSMIT

Send your splice cycle data to the Dashboard on a regular basis to help with troubleshooting and improved splice reliability.



CONNECT TO WI-FI

The press will notify you when a new firmware update is available. Load at your convenience.



NOTE: BLE and Wi-Fi compliant in the following countries:
Canada, Europe, United Kingdom, and United States

Visit www.flexco.com for other Flexco locations and products.

©2025 Flexible Steel Lacing Company. Novitool® is a registered trademark. 05/13/25. 112462

