

Ready Set Dual Action Gold Class Plus Applicator Tool (55590RPR)

Repair Sheet

During the refurbishment process, the Ready Set Dual Action Gold Class Plus applicator tool is completely disassembled and all components are inspected for wear. Certain components are replaced regardless of their condition. These components include the anvil plate, guide blocks, cam levers, bronze bearings, cardboard box, and foam inserts. During refurbishment, the entire tool is cleaned, oiled, and worn components are replaced.

DESCRIPTION	PART EXPLANATION
INSERTS TOP/BOT RSDA	Foam inserts to hold the product in place during shipping
BEARING BRNZ 1/4IDx3/8ODx7/8"	Bronze bearing
ASSY AR CAM LEVER	Lever that allows user to clamp belt
ASSY GUIDE BLOCK RSPD	Guide blocks for driver
CTN MAILER RSDA-24	Box that product is shipped in
SUBASSY ANVIL PLATE RSDA	Applicator tool that directs the staples after they are driven through the belt
BEARING BRNZ 3/16IDx5/16ODx.5"	Bronze bearing

*These components are always replaced.

NOTE: Other components are not replaced during normal refurbishment.

Visit www.flexco.com for other Flexco locations and products, or to find an authorized distributor.

