

Tug™ HD® Belt Clamp Lok Cap Kit Instructions

How to Remove and Lock TUG™ Lok Cap Kits to TUG™ HD® Belt Clamp Ends

1. Loosen the coupling nut by turning it counterclockwise. Once fully loosened, take it out.
2. After removing the coupling nut, gently pull out the turn handle from its position (Fig. 2). This step is necessary to create space for securely placing the Lok Cap onto the Tug Clamp End.
3. After removing the turn handle, carefully place the Lok Cap onto the designated position on the clamp end. Ensure it is aligned correctly and sits securely before proceeding to the next step.
4. Once the Lok Cap is in place, apply the lock to secure the assembly, ensuring it is properly fastened (Fig. 3).

