Prevent Costly, Unscheduled Downtime During Sortation

Flexco recognizes transferring product safely from one belt to another, or from belt to chute or other structure, is often one of the biggest problems for parcel handling operations. FOD anywhere along the line has the potential to damage the belt, compound product loss, or even worse, shut down the system completely. Segmented Transfer Plates provide a safe transition of products throughout the sortation process to help prevent unscheduled downtime, increase operator safety, and reduce pinch hazards at the transfer point. Individual segments snap onto the mounting bar to accommodate belts up to 60" (1500 mm) and gaps from 4" to 10" (100 mm to 250 mm). Segments quickly release under pressure of trapped objects and the bright yellow color makes them easy to monitor for replacement.




Features and Benefits:

- Bright yellow color makes segments easy to monitor for replacement.
- Compatible with both endless and mechanical belt splices.
- Ideal for package handling and airport applications.
- Precision-molded segments ensure accurate fit of transfer in gap.
- Durable HDPE segments ensure long term protection.
- Beveled plastic segments positioned directly on the belt prevent product ingestion and reduce pinch points.

Patent 9,663,306 and Other Patents Pending

www.flexco.com



Provides a **smooth transition** at the transfer point.



HDPE segments lock together and provide a low coefficient of friction so **product slides easily across the transfer**.




Increase the safety of your conveyor by **reducing pinch points**.



SEGMENTED TRANSFER PLATES

4-10" Gaps



Segments are available in 1 inch increments from 2" to 5" (50 mm to 125 mm) lengths.



Different segment lengths can be paired together to provide **options for offset mounting** to accommodate structure variations.




Bar Mounted Segments are easy to install and quickly release under pressure of trapped objects.



The two piece mounting bracket allows for **easy** mounting and removal.


How To Order

- Specify belt width. Mounting bar is 2" longer than specified belt width.
- 2. Determine transfer size required.
- 3. Determine mounting bar location and if offset is required.



For horizontal to horizontal belt applications. Measure distance between pulleys at a point no more than 25% of

the pulley diameter (including belt thickness) down from the crown of both pulleys. For waterfall applications. Measure distance from about 45° from the top of the upper pulley to the top point on the lower pulley.



For belt to chute or slide applications. On pulley side, position no higher than 1/2" below the crown with bridge segment positioned roughly 1/8" to 1/2" above the top of the chute or slide back wall.

For Horizontal to Horizontal or Waterfall Applications and Gaps from 4" to 10" (100 mm to 250 mm)

		Mau	atina						Belt Widths				
	nster		Mounting Bar		24" (610 mm)	36" (914 mm)			42" (1067 mm)		48" (1219 mm)	60" (1524 mm)	
	lidth	Offset		ltem Code	Ordering Number	ltem Code	Ordering Number	ltem Code	Ordering Number	ltem Code	Ordering Number	ltem Code	Ordering Number
IN	mm	in	mm	0000		0000	Humbon	oouo		oouo	Humber	ooue	itamber
4"	102	no	ne	56100	TGB-4/102-2/2-24/610	56101	TGB-4/102-2/2-36/914	56181	TGB-4/102-2/2-42/1067	56102	TGB-4/102-2/2-48/1219	56103	TGB-4/102-2/2-60/1524
5"	127	0.5"	13	56104	TGB-5/127-2/3-24/610	56105	TGB-5/127-2/3-36/914	56182	TGB-5/127-2/3-42/1067	56106	TGB-5/127-2/3-48/1219	56107	TGB-5/127-2/3-60/1524
6"	152	1.0"	25	56108	TGB-6/152-2/4-24/610	56109	TGB-6/152-2/4-36/914	56183	TGB-6/152-2/4-42/1067	56110	TGB-6/152-2/4-48/1219	56111	TGB-6/152-2/4-60/1524
0	152	no	ne	56112	TGB-6/152-3/3-24/610	56113	TGB-6/152-3/3-36/914	56184	TGB-6/152-3/3-42/1067	56114	TGB-6/152-3/3-48/1219	56115 TGB-6/1	TGB-6/152-3/3-60/1524
7"	178	1.5"	38	56116	TGB-7/178-2/5-24/610	56117	TGB-7/178-2/5-36/914	56185	TGB-7/178-2/5-42/1067	56118	TGB-7/178-2/5-48/1219	56119	TGB-7/178-2/5-60/1524
'	1/0	0.5"	13	56120	TGB-7/178-3/4-24/610	56121	TGB-7/178-3/4-36/914	56186	TGB-7/178-3/4-42/1067	56122	TGB-7/178-3/4-48/1219	56123	TGB-7/178-3/4-60/1524
8"	203	1.0"	25	56128	TGB-8/203-3/5-24/610	56129	TGB-8/203-3/5-36/914	56187	TGB-8/203-3/5-42/1067	56130	TGB-8/203-3/5-48/1219	56131	TGB-8/203-3/5-60/1524
°	203	no	ne	56132	TGB-8/203-4/4-24/610	56133	TGB-8/203-4/4-36/914	56188	TGB-8/203-4/4-42/1067	56134	TGB-8/203-4/4-48/1219	56135	TGB-8/203-4/4-60/1524
9"	229	0.5"	13	56140	TGB-9/229-4/5-24/610	56141	TGB-9/229-4/5-36/914	56189	TGB-9/229-4/5-42/1067	56142	TGB-9/229-4/5-48/1219	56143	TGB-9/229-4/5-60/1524
10"	254	none		56148	TGB-10/254-5/5-24/610	56149	TGB-10/254-5/5-36/914	56190	TGB-10/254-5/5-42/1067	56150	TGB-10/254-5/5-48/1219	56151	TGB-10/254-5/5-60/1524

For Belt to Chute or Slide Applications and Gaps from 3" to 6" (75 mm to 150 mm)

									Belt Widths						
	nster	Niou	nting ar		24" (610 mm)	:	36" (914 mm)		42" (1067 mm)		48" (1219 mm)		60" (1524 mm)		
W	idth	Offset		Item	Ordering	Item	Ordering	Item	Ordering	Item	Ordering	Item	Ordering		
in	mm	in	mm	Code	Number	Code	Number	Code	Number	Code	Number	Code	Number		
3"	76	0.5"	12	56206	TGB-3/76-2/B-24/610	56207	TGB-3/76-2/B-36/914	56208	TGB-3/76-2/B-42/1067	56209	TGB-3/76-2/B-48/1219	56210	TGB-3/76-2/B-60/1524		
4"	102	1.0"	25	56211	TGB-4/102-3/B-24/610	56212	TGB-4/102-3/B-36/914	56213	TGB-4/102-3/B-42/1067	56214	TGB-4/102-3/B-48/1219	56215	TGB-4/102-3/B-60/1524		
5"	127	1.5"	38	56216	TGB-5/127-4/B-24/610	56217	TGB-5/127-4/B-36/914	56218	TGB-5/127-4/B-42/1067	56219	TGB-5/127-4/B-48/1219	56220	TGB-5/127-4/B-60/1524		
6"	152	2.0"	51	56221	TGB-6/152-5/B-24/610	56222	TGB-6/152-5/B-36/914	56223	TGB-6/152-5/B-42/1067	56224	TGB-6/152-5/B-48/1219	56225	TGB-6/152-5/B-60/1524		

www.flexco.com


SEGMENTED TRANSFER PLATES

1.5 to 3" Gaps

A Segmented Transfer Plate option is available for narrower **gaps from 1.5" to 3" (38 mm to 75 mm).**

Combinations of **paired segments lock together** inside the support bar to create the span required for the application.





Raised Ribs help reduce the surface friction on the shorter transitions – especially important for the consistency in metered spacing when lighter parcels and packages are being conveyed.


Easy to configure mounting plates provide flexibility in installation options.





How To Order


- Specify belt width. Mounting bar is 2" longer than specified belt width.
- 2. Determine transfer size required.
- 3. Determine mounting bar location.
- 4. Segmented Transfer Plate 1.5" to 3" gaps are not recommended for belt to chute/slide applications.



For horizontal to horizontal belt applications. Measure distance between pulleys at a point no more than 25% of the pulley diameter (including belt

thickness) down from the crown of

both pulleys.



For waterfall applications. Measure distance from about 45° from the top of the upper pulley to the top point on the lower pulley.

(38	(38 mm to 75 mm)													
					Belt Widths									
	nsfer		nting ar		24" (610 mm)		36" (914 mm)		42" (1067 mm)					
Wi	dth	Ith Offset Item Ordering Item		Ordering	Item									
in	mm	in mm		Code	Number	Code	Number	Code	Ordering Number					
1.5"	38	nc	one	56227	TGB-1.5/3875/.75-24/610	56228	TGB-1.5/3875/.75-36/914	56229	TGB-1.5/3875/.75-42/1067					
1.75"	44	0.125"	3.2	56232	TGB-1.75/44-1/.75-24/610	56233	TGB-1.75/44-1/.75-36/914	56234	TGB-1.75/44-1/.75-42/1067					
2.0"	51	nc	none 56237		TGB-2/51-1/1-24/610	56238	TGB-2/51-1/1-36/914	56239	TGB-2/51-1/1-42/1067					
2.25"	57	0.375"	9.5	56242	TGB-2.25/57-1.5/.75-24/610	56243	TGB-2.25/57-1.5/.75-36/914	56244	TGB-2.25/57-1.5/.75-42/1067					
2.5"	64	.250"	6.4	56247	TGB-2.5/64-1.5/1-24/610	56248	TGB-2.5/64-1.5/1-36/914	56249	TGB-2.5/64-1.5/1-42/1067					
3.0"	76	none		56252	TGB-3/76-1.5/1.5-24/610	56253	TGB-3/76-1.5/1.5-36/914	56254	TGB-3/76-1.5/1.5-42/1067					

For Horizontal to Horizontal or Waterfall Applications and Gaps from 1.5" to 3"

For Horizontal to Horizontal or Waterfall Applications and Gaps from 1.5" to 3" (38 mm to 75 mm)

				Belt Widths							
	nsfer		nting ar		48" (1219 mm)	60" (1524 mm)					
Wi	dth	Offset		Item	Ordering	ltem Code	Ordering				
in	n mm in mm		Code	Code Number		Number					
1.5"	38	none		56230	TGB-1.5/3875/.75-48/1219	56231	TGB-1.5/3875/.75-60/1524				
1.75"	44	0.125" 3.2		56235	TGB-1.75/44-1/.75-48/1219	56236	TGB-1.75/44-1/.75-60/1524				
2.0"	51	none		56240	TGB-2/51-1/1-48/1219	56241	TGB-2/51-1/1-60/1524				
2.25"	57	0.375"	9.5	56245	TGB-2.25/57-1.5/.75-48/1219	56246	TGB-2.25/57-1.5/.75-60/1524				
2.5"	2.5" 64 .250"		6.4	56250	TGB-2.5/64-1.5/1-48/1219	56251	TGB-2.5/64-1.5/1-60/1524				
3.0"	3.0" 76		ne	56255	TGB-3/76-1.5/1.5-48/1219	56256	TGB-3/76-1.5/1.5-60/1524				



3

Unique, patented design



Easy to install: Mount the Hitch Guard to your conveyor with simple brackets and hardware, then install segments with a light mallet tap.



Snap-fit design: The 3" segments are designed to release under pressure if small objects become lodged between belt and segments.



Protection and Safety: UHMW plastic segments have a beveled design that prevents progressive belt damage and reduces pinch points.


Hitch Guard

The Hitch Guard from Flexco is engineered to provide a smooth transition of product, increasing safety at the conveyor hitch and reducing pinch hazards at the transfer point. The Hitch Guard prevents small objects from becoming lodged in the hitch which can cause longitudinal conveyor belt tears, damage to conveyed products, and costly periods of unscheduled downtime. Designed to permit individual segments to release from the support bar, objects are quickly dislodged while remaining segments stay secured for continued operation.

Choose from a Universal Mounting System that fits most applications or a Scanner Eye Mounting System that doesn't interfere with electronic scanner eyes, but still keeps hitch protected.

Each Hitch Guard comes with a specially designed gauge for proper positioning in the hitch allowing for optimal installation and performance. See Hitch Guard Installation Specifications chart below to determine if the Flexco Hitch Guard is appropriate for your conveyor hitch.

Hitch Guard Installation Specifications										
Pulley Diameter (inches) (including belt)	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.5	
Minimum Gap Required (inches)	0.8	0.5	0.1	0	0	0	0	0	0	
Maximum Gap (inches)	1.6	1.4	1.2	1.0	0.8	0.6	0.4	0.2	0	



Hitch Guard Ordering Information												
	imum	Universal Mo	unting Bracket	Scanner Eye Mounting Bracket								
	veyor dth	Ordering	ltem	Ordering	ltem							
in	mm	Number	Code	Number	Code							
36"	900	HITCHGD-V3-KIT-36IN	04442	HITCHGD-V1-KIT-36IN	04322							
42"	1050	HITCHGD-V3-KIT-42IN	04443	HITCHGD-V1-KIT-42IN	04321							
48"	1200	HITCHGD-V3-KIT-48IN	04444	HITCHGD-V1-KIT-48IN	04320							
60"	1500	HITCHGD-V3-KIT-60IN	04445	HITCHGD-V1-KIT-60IN	04319							
72"	1800	HITCHGD-V3-KIT-72IN	04988	HITCHGD-V1-KIT-72IN	04973							

Authorized Distributor:



2525 Wisconsin Avenue • Downers Grove, IL 60515-4200 • USA Tel: (630) 971-0150 • Fax: (630) 971-1180 • E-mail: info@flexco.com

Visit www.flexco.com for other Flexco locations and products.

4

