
Laser Belt Square Bias Tool

Instructions for Installation




1. Depress spring loaded pin found on the bottom of Laser Belt Square (LBS) and engage with the larger of the 3 pins on the bias template. Do this so that the tool can swivel and contact each of the smaller pins.



2. Place the tool and template on the belt and position it such that the pin protruding from the under side of the template is in contact with the edge of the belt.



3. Direct the laser so that one laser spans the width of the belt and the other is directed down the intended useable belt.



4. Turn the LBS on by depressing the black power switch (Caution is to be taken when directing the laser beams).



5. Align the laser that is directed down the length of the belt with the belt edge. Maintain contact with one of the 2 pins on the template with the LBS as well as maintain contact between the bottom side template pin and the edge of the belt.

• The grey magnetic targets on the LBS can be used to assist with visibility of the laser.



6. Once laser is aligned rotate the LBS without moving the template until it is in contact with the opposite pin.



 ${\bf 7.}$ The laser crossing the width of the belt is now aligned on a bias.



8. Mark at 2 or more locations along the belt width on the laser line.



9. Use a straight edge or equivalent aligned with the 2 marked points to draw the bias cut line.

10. Repeat steps while maintaining the same rotation direction of the LBS for the other end of the belt or after cutting one belt end use the belt to mark the opposite end of the belt.

