

***Follow these Best Practices
when using your
Flexco® Electric Powered Rivet Driver***

**Always spray Guide Block with
SL5 Silicone.**

This allows for easier insertion and removal of the drive rod.

**Keep the tool perpendicular to the
base when driving rivets.**

This keeps the drive rod on the head of the rivet to give the best rivet drive.

Do not overdrive rivets.

Drive rivets for approximately 1 to 2 seconds depending on the length of rivet and type of belt. Additional driving may damage rivets.

Do not lean on tool.

The use of too much force will impair efficiency.

***Follow these Best Practices
when using your
Flexco® Electric Powered Rivet Driver***

**Always spray Guide Block with
SL5 Silicone.**

This allows for easier insertion and removal of the drive rod.

**Keep the tool perpendicular to the
base when driving rivets.**

This keeps the drive rod on the head of the rivet to give the best rivet drive.

Do not overdrive rivets.

Drive rivets for approximately 1 to 2 seconds depending on the length of rivet and type of belt. Additional driving may damage rivets.

Do not lean on tool.

The use of too much force will impair efficiency.