Segmented Transfer Plates

Prevent Costly, Unscheduled Downtime During Sortation

Flexco recognizes transferring product safely from one belt to another, or from belt to chute or other structure, is often one of the biggest problems for parcel handling operations. FOD anywhere along the line has the potential to damage the belt, compound product loss, or even worse, shut down the system completely. Segmented Transfer Plates provide a safe transition of products throughout the sortation process to help prevent unscheduled downtime, increase operator safety, and reduce pinch hazards at the transfer point. Individual segments snap onto the mounting bar to accommodate belts up to 1500 mm and gaps from 100 mm to 250 mm. Segments quickly release under pressure of trapped objects and the bright yellow color makes them easy to monitor for replacement.



Features and Benefits:


- Bright yellow color makes segments easy to monitor for replacement.
- Compatible with both endless and mechanical belt splices.
- Ideal for package handling and airport applications.
- Precision-molded segments ensure accurate fit of transfer in gap.
- Durable HDPE segments ensure long term protection.
- Beveled plastic segments positioned directly on the belt prevent product ingestion and reduce pinch points.



Provides a **smooth transition** at the transfer point.



HDPE segments lock together and provide a low coefficient of friction so **product** slides easily across the transfer.



Increase the safety of your conveyor by **reducing pinch points.**




www.flexco.com



SEGMENTED TRANSFER PLATES

100-250 mm Gaps



Segments are available in 25 mm increments from (50 mm to 125 mm) lengths.



Different segment lengths can be paired together to provide **options for offset mounting** to accommodate structure variations.




Bar Mounted Segments are easy to install and quickly release under pressure of trapped objects.



The two piece mounting bracket allows for **easy mounting and removal**.


How To Order

- Specify belt width. Mounting bar is
 mm longer than specified belt width.
- 2. Determine transfer size required.
- 3. Determine mounting bar location and if offset is required.




For horizontal to horizontal belt applications. Measure distance between pulleys at a point no more than 25% of

the pulley diameter (including belt thickness) down from the crown of both pulleys.



For waterfall applications. Measure distance from about 45° from the top of the upper pulley to the top point on the lower pulley.



For belt to chute or slide applications. On pulley side, position no higher than 12 mm below the crown with bridge segment positioned roughly 3 to 12 mm above the top of the chute or slide back wall.

For Horizontal to Horizontal or Waterfall Applications and Gaps from 100 mm to 250 mm

| | Mounting | Belt Widths | | | | | | | | | | |
|-------------------|---------------|--------------|-----------------------|--------------|-----------------------|--------------|------------------------|--------------|------------------------|--------------|------------------------|--|
| Transfer Width | Bar Offset | | 610 mm | | 914 mm | | 1067 mm | | 1219 mm | | 1524 mm | |
| | | ltem Code | Ordering Number | ltem Code | Ordering Number | ltem Code | Ordering Number | ltem Code | Ordering Number | ltem Code | Ordering Number | |
| mm | mm | 0000 | Hambol | 0000 | Humbon | 0000 | Humbon | 0000 | Humber | 0000 | Humber | |
| 102 | none | 56100 | TGB-4/102-2/2-24/610 | 56101 | TGB-4/102-2/2-36/914 | 56181 | TGB-4/102-2/2-42/1067 | 56102 | TGB-4/102-2/2-48/1219 | 56103 | TGB-4/102-2/2-60/1524 | |
| 127 | 13 | 56104 | TGB-5/127-2/3-24/610 | 56105 | TGB-5/127-2/3-36/914 | 56182 | TGB-5/127-2/3-42/1067 | 56106 | TGB-5/127-2/3-48/1219 | 56107 | TGB-5/127-2/3-60/1524 | |
| 152 | 25 | 56108 | TGB-6/152-2/4-24/610 | 56109 | TGB-6/152-2/4-36/914 | 56183 | TGB-6/152-2/4-42/1067 | 56110 | TGB-6/152-2/4-48/1219 | 56111 | TGB-6/152-2/4-60/1524 | |
| 102 | none | 56112 | TGB-6/152-3/3-24/610 | 56113 | TGB-6/152-3/3-36/914 | 56184 | TGB-6/152-3/3-42/1067 | 56114 | TGB-6/152-3/3-48/1219 | 56115 | TGB-6/152-3/3-60/1524 | |
| 178 | 38 | 56116 | TGB-7/178-2/5-24/610 | 56117 | TGB-7/178-2/5-36/914 | 56185 | TGB-7/178-2/5-42/1067 | 56118 | TGB-7/178-2/5-48/1219 | 56119 | TGB-7/178-2/5-60/1524 | |
| 170 | 13 | 56120 | TGB-7/178-3/4-24/610 | 56121 | TGB-7/178-3/4-36/914 | 56186 | TGB-7/178-3/4-42/1067 | 56122 | TGB-7/178-3/4-48/1219 | 56123 | TGB-7/178-3/4-60/1524 | |
| 203 | 25 | 56128 | TGB-8/203-3/5-24/610 | 56129 | TGB-8/203-3/5-36/914 | 56187 | TGB-8/203-3/5-42/1067 | 56130 | TGB-8/203-3/5-48/1219 | 56131 | TGB-8/203-3/5-60/1524 | |
| 203 | none | 56132 | TGB-8/203-4/4-24/610 | 56133 | TGB-8/203-4/4-36/914 | 56188 | TGB-8/203-4/4-42/1067 | 56134 | TGB-8/203-4/4-48/1219 | 56135 | TGB-8/203-4/4-60/1524 | |
| 229 | 13 | 56140 | TGB-9/229-4/5-24/610 | 56141 | TGB-9/229-4/5-36/914 | 56189 | TGB-9/229-4/5-42/1067 | 56142 | TGB-9/229-4/5-48/1219 | 56143 | TGB-9/229-4/5-60/1524 | |
| 254 | none | 56148 | TGB-10/254-5/5-24/610 | 56149 | TGB-10/254-5/5-36/914 | 56190 | TGB-10/254-5/5-42/1067 | 56150 | TGB-10/254-5/5-48/1219 | 56151 | TGB-10/254-5/5-60/1524 | |

For Belt to Chute or Slide Applications and Gaps from 75 mm to 150 mm

| | | | | | | | | Belt Widths | | | | de Number 10 TGB-3/76-2/B-60/1524 15 TGB-4/102-3/B-60/1524 | |
|-------------------|----------|-----|--------|----------------------|-------|----------------------|-------|-----------------------|-------|-----------------------|-------|---|--|
| Transfer Width | | U U | 610 mm | | | 914 mm | | 1067 mm | | 1219 mm | | 1524 mm | |
| | th Offse | et | tem | Ordering | Item | Ordering | Item | Ordering | Item | Ordering | Item | | |
| mr | n mm | | ode | Number | Code | Number | Code | Number | Code | Number | Code | Number | |
| 76 | 12 | 56 | 6206 | TGB-3/76-2/B-24/610 | 56207 | TGB-3/76-2/B-36/914 | 56208 | TGB-3/76-2/B-42/1067 | 56209 | TGB-3/76-2/B-48/1219 | 56210 | TGB-3/76-2/B-60/1524 | |
| 10 | 2 25 | 56 | 6211 | TGB-4/102-3/B-24/610 | 56212 | TGB-4/102-3/B-36/914 | 56213 | TGB-4/102-3/B-42/1067 | 56214 | TGB-4/102-3/B-48/1219 | 56215 | TGB-4/102-3/B-60/1524 | |
| 12 | 38 | 56 | 6216 | TGB-5/127-4/B-24/610 | 56217 | TGB-5/127-4/B-36/914 | 56218 | TGB-5/127-4/B-42/1067 | 56219 | TGB-5/127-4/B-48/1219 | 56220 | TGB-5/127-4/B-60/1524 | |
| 15 | 2 51 | 56 | 6221 | TGB-6/152-5/B-24/610 | 56222 | TGB-6/152-5/B-36/914 | 56223 | TGB-6/152-5/B-42/1067 | 56224 | TGB-6/152-5/B-48/1219 | 56225 | TGB-6/152-5/B-60/1524 | |

www.flexco.com

SEGMENTED TRANSFER PLATES

38-75 mm Gaps

A Segmented Transfer Plate option is available for narrower **gaps from (38 mm to 75 mm)**.

Combinations of **paired segments lock together** inside the support bar to create the span required for the application.





Raised Ribs help reduce the surface friction on the shorter transitions – especially important for the consistency in metered spacing when lighter parcels and packages are being conveyed.


Easy to configure mounting plates provide **flexibility in installation** options.






How To Order

- Specify belt width. Mounting bar is
 mm longer than specified belt width.
- 2. Determine transfer size required.
- 3. Determine mounting bar location.
- 4. Segmented Transfer Plate 38 to 75 mm gaps are not recommended for belt to chute/slide applications.



For horizontal to horizontal belt applications. Measure distance between pulleys at a point no more than 25% of the pulley diameter (including belt thickness) down from the crown of both pulleys.



For waterfall applications. Measure distance from about 45° from the top of the upper pulley to the top point on the lower pulley.

| | | Belt Widths | | | | | | | | | | |
|----------|-----------------|-------------|----------------------------|-------|----------------------------|-------|-----------------------------|--|--|--|--|--|
| Transfer | Mounting Bar | | 610 mm | | 914 mm | | 1067 mm | | | | | |
| Width | Offset | Item | Ordering | Item | Ordering | Item | | | | | | |
| mm | mm | Code | Number | Code | Number | Code | Ordering Number | | | | | |
| 38 | none | 56227 | TGB-1.5/3875/.75-24/610 | 56228 | TGB-1.5/3875/.75-36/914 | 56229 | TGB-1.5/3875/.75-42/1067 | | | | | |
| 44 | 3.2 | 56232 | TGB-1.75/44-1/.75-24/610 | 56233 | TGB-1.75/44-1/.75-36/914 | 56234 | TGB-1.75/44-1/.75-42/1067 | | | | | |
| 51 | none | 56237 | TGB-2/51-1/1-24/610 | 56238 | TGB-2/51-1/1-36/914 | 56239 | TGB-2/51-1/1-42/1067 | | | | | |
| 57 | 9.5 | 56242 | TGB-2.25/57-1.5/.75-24/610 | 56243 | TGB-2.25/57-1.5/.75-36/914 | 56244 | TGB-2.25/57-1.5/.75-42/1067 | | | | | |
| 64 | 6.4 | 56247 | TGB-2.5/64-1.5/1-24/610 | 56248 | TGB-2.5/64-1.5/1-36/914 | 56249 | TGB-2.5/64-1.5/1-42/1067 | | | | | |
| 76 | none | 56252 | TGB-3/76-1.5/1.5-24/610 | 56253 | TGB-3/76-1.5/1.5-36/914 | 56254 | TGB-3/76-1.5/1.5-42/1067 | | | | | |

For Horizontal to Horizontal or Waterfall Applications and Gaps from (38 mm to 75 mn

For Horizontal to Horizontal or Waterfall Applications and Gaps from (38 mm to 75 mm)

| | | Belt Widths | | | | | | | | |
|----------|-----------------|-------------|-----------------------------|---------|-----------------------------|--|--|--|--|--|
| Transfer | Mounting Bar | | 1219 mm | 1524 mm | | | | | | |
| Width | Offset | Item | Ordering | Item | Ordering | | | | | |
| mm | mm | Code | Number | Code | Number | | | | | |
| 38 | none | 56230 | TGB-1.5/3875/.75-48/1219 | 56231 | TGB-1.5/3875/.75-60/1524 | | | | | |
| 44 | 3.2 | 56235 | TGB-1.75/44-1/.75-48/1219 | 56236 | TGB-1.75/44-1/.75-60/1524 | | | | | |
| 51 | none | 56240 | TGB-2/51-1/1-48/1219 | 56241 | TGB-2/51-1/1-60/1524 | | | | | |
| 57 | 9.5 | 56245 | TGB-2.25/57-1.5/.75-48/1219 | 56246 | TGB-2.25/57-1.5/.75-60/1524 | | | | | |
| 64 | 6.4 | 56250 | TGB-2.5/64-1.5/1-48/1219 | 56251 | TGB-2.5/64-1.5/1-60/1524 | | | | | |
| 76 | none | 56255 | TGB-3/76-1.5/1.5-48/1219 | 56256 | TGB-3/76-1.5/1.5-60/1524 | | | | | |



Unique, patented design



Easy to install: Mount the Hitch Guard to your conveyor with simple brackets and hardware, then install segments with a light mallet tap.



Snap-fit design: The 3" segments are designed to release under pressure if small objects become lodged between belt and segments.



Protection and Safety: UHMW plastic segments have a beveled design that prevents progressive belt damage and reduces pinch points.


Hitch Guard

The Hitch Guard from Flexco is engineered to provide a smooth transition of product, increasing safety at the conveyor hitch and reducing pinch hazards at the transfer point. The Hitch Guard prevents small objects from becoming lodged in the hitch which can cause longitudinal conveyor belt tears, damage to conveyed products, and costly periods of unscheduled downtime. Designed to permit individual segments to release from the support bar, objects are quickly dislodged while remaining segments stay secured for continued operation.

Choose from a Universal Mounting System that fits most applications or a Scanner Eye Mounting System that doesn't interfere with electronic scanner eyes, but still keeps hitch protected.

Each Hitch Guard comes with a specially designed gauge for proper positioning in the hitch allowing for optimal installation and performance. See Hitch Guard Installation Specifications chart below to determine if the Flexco Hitch Guard is appropriate for your conveyor hitch.

| Hitch Guard Installation Specifications | | | | | | | | | | | |
|---|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|
| Pulley Diameter (including belt) | 63.5 mm | 76.2 mm | 88.9 mm | 101.6 mm | 114.3 mm | 127 mm | 139.7 mm | 152.4 mm | 165.1 mm | | |
| Minimum Gap Required | 20.32 mm | 12.7 mm | 2.54 mm | 0 | 0 | 0 | 0 | 0 | 0 | | |
| Maximum Gap | 40.64 mm | 35.56 mm | 30.48 mm | 25.4 mm | 20.32 mm | 15.24 mm | 10.16 mm | 5.08 mm | 0 | | |



| Hitch Guard Ordering Information | | | | | | | | | | |
|----------------------------------|---------------------|----------------|------------------------------|-------|--|--|--|--|--|--|
| Maximum | Universal Mou | unting Bracket | Scanner Eye Mounting Bracket | | | | | | | |
| Conveyor Width | Ordering | ltem | Ordering | ltem | | | | | | |
| mm | Number | Code | Number | Code | | | | | | |
| 900 | HITCHGD-V3-KIT-36IN | 04442 | HITCHGD-V1-KIT-36IN | 04322 | | | | | | |
| 1050 | HITCHGD-V3-KIT-42IN | 04443 | HITCHGD-V1-KIT-42IN | 04321 | | | | | | |
| 1200 | HITCHGD-V3-KIT-48IN | 04444 | HITCHGD-V1-KIT-48IN | 04320 | | | | | | |
| 1500 | HITCHGD-V3-KIT-60IN | 04445 | HITCHGD-V1-KIT-60IN | 04319 | | | | | | |
| 1800 | HITCHGD-V3-KIT-72IN | 04988 | HITCHGD-V1-KIT-72IN | 04973 | | | | | | |

. Authorised Distributor:



4

236 Albert Amon Rd • Meadowdale Ext. 7 • Germiston 1614 • South Africa Tel: +27-11-608-4180 • Fax: +27-11-454-5821 • E-mail: flexco@flexco.co.za

Visit www.flexco.com for other Flexco locations and products.

©2017 Flexible Steel Lacing Company. 12-28-21. X5243